

GUIDE OF MC100 LED SHOW



WeChat Official Accounts

Guide of MC100 LED SHOW



Download MC100 LED SHOW from www.mc100.com.cn.

Or from Web Link <http://www.lmshow.net/mc100/mc100.apk>

Or Scan two-dimensional code download from WeChat.



MC100 SHOW introduction :

It supports playing pictures, GIF pictures, text, multiple lines of text, video and music.


Simple operation, easy to use, asynchronous playing.


make programs :


Click on the home button





Set the width and height resolution (Unit is point ,Then you can reset it in the lower right corner).







Click on the button  , You can choose the templet. In the middle area, you can double-click on the area to modify.





Or you can click the button . You can add the program box as shown.





Save and upload :

When editing and completing the program , you can click the button





in the upper right corner.






Select your LED, you can click the button to upload the program.





You can also click the button in the first interface.

Open the show you saved and You can edit it again.



Connection :

We connect the WIFI (Mc100ap-xxxx) with the mobile phone, open the MC100 LED show (Click the switch language at the top right corner), click the LED setting in the main interface.



Select the LED